


# Magstripe Reader Installation Template



## Surface Mount Fixing onto Wood



Using a 2mm diameter pilot drill bit, drill to a depth of 35mm minimum. Fix the backplate to the wall with the screws supplied.



Fit the reader to the backplate and secure with the grub screw supplied.

## Surface Mount Fixing onto Masonry



Using a 6mm diameter masonry drill bit, drill to a depth of 35mm minimum. Fix the backplate to the wall with the rawl plugs and screws supplied.



Fit the reader to the backplate and secure with the grub screw supplied.

## Through-Wall Fixing studding sold separately



Using the two countersunk screws supplied, fix the backplate to the housing.



Screw the M5 studding to the backplate and insert both rods through the wall and secure from the internal side.

## Wiring Details



Red +VDC Supply (5-18)



White Data (Wiegand 1)



Blue Card Present



Black OVDC Signal Gnd



Green Clock (Wiegand 0)



Violet Not in use



Yellow Buzzer Control



Orange Green / Yellow LED